

# Portland Pudgy

## Mounting Instructions

Picture #1

Use the long Pudgy loop for the bow of the dinghy, see **picture #1**, and the short Pudgy loop goes on the transom of the dinghy. **See picture #2**



The holes through the side of the Pudgy should already have 3/4" Sch. 40 PVC pipe for a liner.

Put the Pudgy loop through the hole in the side of boat. Center washer over the hole and rod on inside of the boat. Mark small holes for drilling. Check access through side - if you can't reach the back side of holes, use 1/4" x 1 Sheet Metal screws. The front seat can be removed for drilling.

Drill 1/4" holes for the bolts. Insert 1/4"-20x1" pan head bolts and secure with nyloc nuts and washers. **See picture #3**

Picture #2



For mounting the davits on the swim platform, place the dinghy on the back of the swim platform. Line every thing up and mark the davits so they line up with the dinghy. Drill 1/4" holes into the swim platform and use the supplied bolts, nuts and washers to bolt it down. **See picture #4**

Picture #4



Picture #3



**Weaver Industries, Inc.**

6570 W. Boekel Road

Rathdrum, ID 83858

(800) 367-4062 (208) 687-3982 Fax (208) 687-0782

[www.weaverindustries.com](http://www.weaverindustries.com)